



Williams Legato III Firmware Release Notes

To update the Williams Piano:

1. Open *Williams Flash Upload* for Mac or Windows, available from the Williams Piano website
2. Connect a USB cable from your computer to the module. The software should alert you that the piano is connected.
3. Click the Browse button in the application, select the ROM file that you downloaded, then click Update.
4. When the update is complete, disconnect the power and then plug it back in.
5. Hold CHORUS and REVERB while powering on to reset the piano.

Changes in Firmware Version 20181203:

- Fixed MIDI control of ModFX

Changes in Firmware Version 20181102:

- Layer mode can now include Variation sounds
- Fixes for Bluetooth MIDI and transpose

Changes in Firmware Version 20180827:

- Split and layer modes can be controlled over MIDI.

Changes in Firmware Version 20180803:

- Fixes to MIDI messages for effects and metronome

Changes in Firmware Version 20180705:

- First shipping version